

BATTERY REPLACEMENT FOR 5898 MOTION DETECTOR



Please Note: Upon opening the motion detector cover, you may hear your keypad beeping. This is the tamper switch contained in certain model sensors.

After you have replaced the battery, and closed the sensor cover, you will reset your system. This will silence the beeping, and clear the low battery message from the display.

Open the cover: Depress the push tab located on the bottom edge of the sensor (see image to right). Pull bottom of front cover away from wall while pressing the tab.



Remove old battery from sensor: The batteries required for this model is part number "AA" Lithium. Install new batteries. Do not install alkaline batteries!

Close the cover: Engage the tab at the top of the cover first (right image), then swing the bottom down to engage the tab. You should hear a "click" when fully closed.

Please note: A red light will flash after the new battery is installed. This is the sensor test mode. The sensor will remain in test mode for 10-15 minutes, after which the light will be disabled.

You can now reset your system: Enter your 4 digit code and OFF two times. (Code + OFF, Code + OFF)

Your system should now be ready to use again!



**Any Questions? Please give us a call:
408-358-1500**