

BATTERY REPLACEMENT FOR GLASS BREAK MODEL 5853



Please Note: Upon opening the sensor cover, you may hear your keypad beeping. This is the tamper switch contained in certain model sensors.

After you have replaced the battery, and closed the sensor cover, you will reset your system. This will silence the beeping, and clear the low battery message from the display.

Open the cover: Insert flat head screw driver into notched tab on the sensor (see image to right). Twist slightly until cover releases. Open up cover.

Remove old battery or batteries from sensor (Older models have 2). The battery required for this model is part number CR123. Install the new battery.



Close the cover: Swing the cover closed to engage the tab. You should hear a "click" when fully closed.

You can now reset your system: Enter your 4 digit code and OFF two times. (Code + OFF, Code + OFF)
Your system should now be ready to use again!

**Any Questions? Please give us a call:
408-358-1500**